HW 10, matlab solution

Nathan Barton

November 12, 1999

1 Problem 3

The matlab files for the solution are given below. First is the output from the driver file, followed by the driver file itself and then the m-file fan solve.m. The m-files are also available for download from the web page.

Given that I had already programmed the force calculation to work over the full cycle, the m-files are not much different this week. There is the added global variable l_statics which I use to turn on and off the forces from dynamics. It is interesting to note, that for this problem, a statics analysis tells you that the motor is strong enough to drive the mechanism, but when you include the dynamical forces the motor is no longer adequate. You were not required to do the statics version yourselves, I just did it for fun.

1.1 output from driver file

```
>> fan_driver
check of energy conservation -2.031e-08
maximum moment exerted by motor 6.828
maximum moment exerted on motor 10.546
the motor is not capable of driving the mechanism over a cycle
for the case of statics ...
the motor is capable of driving the mechanism over a cycle
```

1.2 Driver file

fan driver.m

% some of the values that are set in this file are not used until later % parts of the problem

global r r2 rg lthg; global iwk iwu1 iwu2 ium; global w_data; global gc g_by_gc; global m ai; global l_statics;

% rated torque of motor max_motor_torque_output = 6.0;

% do as dynamics problem

```
1 \text{ statics} = 0;
% figure counter
ifig = 0;
% some of geometry of linkage
ò
% lengths of bars in linkage (meters)
r = 0.01 * [10.0 40.0 30.0 40.0]';
r2 = r*r';
% angle (relative to local coordinates on link) to the center of mass;
% see m-file linkage ag.m
lthg = [0.0 \ 0.0 \ pi/6]';
% distance to centers of mass from starting point of link
rg = [r(1)*0.5 r(2)*0.5 r(3)/cos(lthg(3))]';
% masses, moments of inertia
m = [0.0 \ 0.0 \ 10.0]'; % in kg
% moment of inertia for uniform distribution of mass over links
ai = zeros(3,1);
ai(1) = m(1) * r2(1,1) / 12.0;
ai(2) = m(2) * r2(2,2) / 12.0;
diam fan = 1.0;
ai(3) = m(3)*diam fan*diam fan/16.0;
% gravitation
        = [0.0 -9.8]'; % direction 2 is down, in m/s<sup>2</sup>
q
        = 1.0; % metric, trust mass to be in kg
ac
g_by_gc = g/gc;
th1 init = atan2(3,4);
th init = fan angles(r,r2,th1 init);
% data for initial angular velocities
w data = [2.0*pi 0.0 0.0]';
% indices for known (iwk) and unknown (iwu*) angular velocities
% and index for unknown moment (ium)
iwk = 1; iwu1 = 2; iwu2 = 3; ium = 1;
tstart = 0.0; tstop = 2.0*pi/abs(w data(iwk)); nt = 101;
tspan = linspace(tstart, tstop, nt);
dtime = (tstop - tstart)/(nt-1);
options = odeset('AbsTol',1e-10);
[t, th num] = ode45('fan solve',tspan,th init,options);
```

```
% obtain accelerations over a full cycle
thdot all = zeros(nt,3);
ag_fan = zeros(nt,2); mag_ag_fan = zeros(nt,1);
thddot fan = zeros(nt); mag thddot fan = zeros(nt,1);
for it = 1:nt;
   [thdot,thddot,ag] = fan_solve(t(it), th_num(it,:));
   % store results at time it
   ag fan(it,:) = ag(:,3)';
   mag_ag_fan(it) = norm(ag(:,3));
   thddot fan(it) = thddot(3);
   mag_thddot_fan(it) = abs(thddot(3));
   thdot all(it,:) = thdot';
end;
% plot all of the angular velocities of the moving links
ifig = ifig+1; figure(ifig);
plot(...
   t, thdot all(:,1), ':', ...
   t, thdot all(:,2), '-', ...
   t, thdot all(:,3), '--')
xlabel('time (s)'); ylabel('angular velocity (radians/s)');
title('angular velocities of links, from numerical integration');
legend('thdot1','thdot2','thdot3');
% plot angular acceleration of link 3
ifig = ifig+1; figure(ifig);
plot(t,thddot fan);
xlabel('time (s)'); ylabel('angular acceleration (rad/s<sup>2</sup>)');
title('angular acceleration of fan for a full cycle');
% plot componenets of linear acceleration of fan's center of mass over cycle
ifig = ifig+1; figure(ifig);
plot(...
   t,ag fan(:,1), '-', ...
   t,ag fan(:,2), '--');
xlabel('time (s)'); ylabel('linear acceleration (m/s<sup>2</sup>)');
title('components of acceleration of fan for a full cycle');
legend('x component','y component');
```

% loop over cycle to get moment at motor

```
ma = zeros(nt, 1);
for it = 1:nt;
[thdot,thddot,ag,f] = fan solve(t(it), th num(it,:));
ma(it) = f(9);
end;
% check of conservation of energy over a cycle, scale the integral
% by the integral of the absolute value (to get the error as a
% relative magnitude)
integ = sum(ma(1:(nt-1)))*dtime*w data(iwk);
integ scale = sum(abs(ma(1:(nt-1))))*w data(iwk);
fprintf('check of energy conservation %.3e\n', ...
integ/integ scale);
if (w data(iwk) > 0.0);
  % moment is in same direction as rotation so work flows into
  % the system when the moment is positive
  sign_wk = sign(w_data(iwk));
else
  % moment is in opposite direction as rotation so work flows into
  % the system when the moment is negative
end
% moment at motor
ifig = ifig+1; figure(ifig);
plot(t,ma*sign wk);
xlabel('time (s)'); ylabel('moment (N/m)');
title('moment for a full cycle; when positive, work flows into system');
max moment by = max( ma*sign wk);
max moment on = max(-ma*sign wk);
°
fprintf('maximum moment exerted by motor %.3f\n',max moment by);
fprintf('maximum moment exerted on motor %.3f\n',max moment on);
if (max_moment_by > max_motor_torque_output);
  fprintf('the motor is not capable of driving the mechanism over a cyclen');
else
  fprintf('the motor is capable of driving the mechanism over a cycle\n');
end
% now check and see if the motor could have driven the fan if we had just
% done statics (not required, but fun to check)
1 \text{ statics} = 1;
ò
```

```
% see fan solve function for the solution this week; all of the kinematics
% are the same, just have to rerun the force and moment calculation
ma statics = zeros(nt,1);
for it = 1:nt;
[thdot,thddot,ag,f] = fan solve(t(it), th num(it,:));
ma statics(it) = f(9);
end;
% moment at motor, statics
ifig = ifig+1; figure(ifig);
plot(t,ma statics*sign wk);
xlabel('time (s)'); ylabel('moment (N/m)');
title ('moment for a full cycle; statics; when positive, work flows into system');
max moment by statics = max( ma statics*sign wk);
fprintf('for the case of statics \ldots \n');
if (max moment by statics > max motor torque output);
  fprintf('the motor is not capable of driving the mechanism over a cycle\n');
else
  fprintf('the motor is capable of driving the mechanism over a cyclen');
end
```

1.3 big chunky matlab file to calculate lots of things

```
fan solve.m
function [thdot,thddot,ag,f] = fan solve(t, th)
ç
% NOTE ON USE OF NARGOUT:
% If this function is not called with all of the output arguments, then
% the extra output arguments are not computed -- no sense in finding the
% values if the caller of the function is not going to use them. For
% example, if this function is passed to ode45 with something like
         [t, th num] = ode45('fan solve',tspan,th init,options);
°
% than ode45 will call fan solve with only one output argument, the
% equivalent of you calling fan solve like
         [thdot] = fan solve(t current, th current);
°
% In that case, only one output argument has been requested, and matlab
% sets the automatic variable nargout to be equal to 1
% INPUT arguments:
%t --
                scalar, input, current time; never used for anything
% th --
                vector of length nlink (number of moving links); angle
                of a link measured counterclockwise from the i-direction
% OUTPUT arguments:
% given angles of components, find:
```

```
vector of length nlink; angular velocities
% thdot --
                vector (nlink); angular accelerations
% thddot --
                matrix (2,nlink); 2 because two-dimensional vector for
         _ _
% ag
                the accelerations; linear acceleration of mass centers
Ŷ
                vector of length 9; 8 forces at pins and 1 unknown moment
% f
         - -
°
% GLOBALS that have been assigned in the driver script
global r r2 rg lthg;
°
     r --
           vector(nlink); length of the link
     r2 -- matrix(nlink,nlink); "squares" of links, r2(i,j)=r(i)*r(j)
°
     rg -- vector(nlink); length from beginning of link to center of mass
Ŷ
÷
     lthg -- vector(nlink); angle from line of link to line from the
             beginning of the link to the center of mass (counterclockwise)
ŝ
global iwk iwu1 iwu2 ium;
     iwk -- scalar; index for link for which angular velocity is known
Ŷ
     iwul -- scalar; index for first link for which angular velocity is unknown
°
     iwu2 -- scalar; index for second link -- || --
ò
÷
     ium -- scalar; index for link to which unknown moment is applied
global w data;
     w data -- vector(nlink); data giving known angular velocity; entry
Ŷ
               iwk is the only number used in this vector
Ŷ
global gc g by gc;
°
             -- scaling used when using English units
     qc
%
     g by gc -- vector(2) giving the direction in which gravity acts
global m ai;
     m -- vector(nlink); masses of links
Ŷ
     ai -- vector(nlink); angular inertia of links
°
global l_statics;
°
     l_statics -- treat as statics problem if true
°
nlink = 3; % number of moving links
if (length(th) ~= nlink);
      disp('error, th of wrong length');
      return;
end;
Ŷ
% GET UNIT VECTORS:
% vectors nvec are along the links and vectors tvec are perpendicular to
% the links and in the direction of motion of the end of the link when
% the angular velocity is positive;
% nvec -- matrix(2,nlink)
% tvec -- matrix(2,nlink)
[nvec, tvec] = linkage_vec(th);
Ŷ
% solve for ANGULAR VELOCITIES;
```

```
% note that tvec(:,i) and nvec(:,i) are column vectors so that
% A becomes a (2,2) matrix and y becomes a 2-column-vector, or (2,1) matrix
°
A = [r(iwu1)*tvec(:,iwu1) r(iwu2)*tvec(:,iwu2)];
y = [w_data(iwk)*r(iwk)*tvec(:,iwk)];
x = -A \setminus y;
Ŷ
% set values in thdot
Ŷ
thdot = zeros(3,1);
thdot(iwk) = w data(iwk);
thdot(iwu1) = x(1);
thdot(iwu2) = x(2);
°
% end of calculation of angular velocities
if (nargout > 1);
ş
% find ANGULAR ACCELERATIONS
ò
% get squares of angular velocities
thdot2 = thdot.*thdot;
% thdot2 -- vector(nlink)
Ŷ
A = [r(iwu1) * tvec(:, iwu1) r(iwu2) * tvec(:, iwu2)];
y = [-thdot2(iwk) * r(iwk) * nvec(:,iwk) + ...
     -thdot2(iwu1)*r(iwu1)*nvec(:,iwu1) + ...
     -thdot2(iwu2)*r(iwu2)*nvec(:,iwu2)];
x = -A \setminus y;
°
% set values in thddot
ò
thddot = zeros(3,1);
thddot(iwk) = 0.0;
thddot(iwu1) = x(1);
thddot(iwu2) = x(2);
end; % end of calculation of angular accelerations
°
if (nargout > 2);
% find LINEAR ACCELERATION of mass centers
Ŷ
[ag,ng] = linkage ag(thdot2,thddot,r,rg,lthg,nvec,tvec);
ò
end; % end calculation of linear acceleration of mass centers
Ŷ
```

```
Ŷ
if (nargout > 3);
Š
% find FORCES AND MOMENT
% The code below works for a sequence of links with forces defined in the
% negative sense at the beginning of a link (connection to previous link)
% and in the position sense at the end of a link (connection to next link)
% We have two equations from force balance and one equation from
% moment balance for each link
ò
neq per link = 2+1; % number of equations per link
neq = nlink*neq per link; % number of total equations
ŝ
% allow only one unknown moment; its index is imd
imd = (nlink+1) * 2 + 1;
2
% zero necessary arrays
A = zeros(neq, neq);
b = zeros(neq, 1);
f = zeros(neq, 1);
% initialize equation counter; as entries are add to the system matrix A,
% this index will keep track of the equation number (row) to which numbers
% are being added;
eq num = 0;
for i_link = 1:nlink; % loop over links
 %
 % equation numbers;
 % ieq -- force equation in the i-direction for the current link
 % jeq -- force equation in the j-direction for the current link
 % meq -- moment equation (in the k-direction) for the current link
 ò
 ieq = eq num+1; jeq = eq num+2; meq = eq num+3;
 °
 % increment the equation counter
 eq num = eq num + neq per link;
 ò
 % force indices for ends of links
 if base = (i link-1) *2;
 % forces at start of link in i and j directions
 ifsi = 1 + if base; ifsj = 2 + if base;
 if base = if base + 2;
 % forces at end of link in i and j directions
 ifei = 1 + if_base; ifej = 2 + if_base;
```

```
Ŷ
 % force equations;
 °
     forces at S act in negative direction and forces at E act in
     positive direction
 Ŷ
A(ieq, [ifsi, ifei]) = [-1.0 1.0];
A(jeq,[ifsj, ifej]) = [-1.0 1.0];
if (l_statics);
   b([ieq,jeq]) = -m(i link)*g by gc(:);
 else
   b([ieq,jeq]) = m(i link)*(ag(:,i link)/gc - g by gc(:));
 end
 ò
 % moment equation, about beginning of link, point S
 %
ntemp = cross 2d ij(nvec(:,i link));
 % ntemp is a 2-vector and you needn't worry about trying to give it a
 % physical meaning, it is simply the vector that when dotted with the
 % force at E (and multiplied by the length of the link) gives the moment
 % about S
 °
A(meq,[ifei,ifej]) = r(i link)*ntemp';
 if (ium == i link);
   %this is the link on which unknown moment is applied
   A(meq, imd) = 1.0;
 end;
 if (1 statics);
   b(meq) = \ldots
        -m(i link)*rg(i link)*cross 2d(ng(:,i link),g by gc);
 else
   b(meq) = ai(i_link)*thddot(i_link)/gc + ...
        +m(i link)*rg(i link)*cross 2d(ng(:,i link),ag(:,i link)) + ...
        -m(i link)*rg(i link)*cross 2d(ng(:,i link),g by gc);
 end;
 8
end; % end of loop over links
°
% finally, ready to solve
Ŷ
f = A \setminus b;
°
end; % end of force and moment calculations
```

For cross_2d.m, cross_2d_ij.m, fan_angles.m, linkage_vec.m, law_cos_len.m, linkage_ag.mand law_cos_ang see previous solutions or the bottom of the matlab part of the web page.









